


## How to connect

### Setting up your new router

Skymesh routers arrive pre-configured. Simply plug in the supplied cables as per the diagram, switch on the new router and connect to it using the supplied WiFi password.

Note: This cabling setup is essential for an active connection. Please avoid changing the cabling setup below to prevent disconnection.



#### Netcomm NF20Mesh

Please plug into the red WAN port

#### nbn® Fixed Wireless NTD

Please plug into the UNI-D sent via email

## Warranty

Your new router comes with a 3-year advanced replacement warranty for full peace of mind. More information on our warranty can be found at **skymesh.net.au/warranty** 

## Understand your nbn® NTD lights

Learn more about your nbn® NTD (Connection Box). If you are offline, please check the cabling setup on the 'How to Connect' page and restart your internet connection. If issues persist, please call us on **1300 759 637**.

Light	State	Meaning
Power		No power supply. All other lights will be off if the nbn® NTD has no power.
		nbn® NTD is operating on backup battery power and power is low (if a battery has been fitted).
		nbn® NTD has power.
	<b>*</b>	nbn® NTD is operating on backup battery power (if a battery has been fitted).
Status		nbn® NTD has no power or is in an unexpected state.
		A system fault is detected.
		nbn® NTD is booting up/initialising.
		nbn® NTD is in test mode.
	- <del>•</del>	nbn® NTD is operating normally.
Outdoor Unit (ODU)		nbn® NTD has no power or is in an unexpected state.
		nbn® NTD is offline.
	- <del>;</del>	An error is detected.
		nbn® NTD is online.
	÷.	Network activity.
Signal Strength		nbn® NTD has no power or is offline.
		Low signal strength (this is not necessarily a service fault as factors such as local weather can impact signal strength).
		Medium signal strength.
		High signal strength.

# How to restart your internet connection

If you're offline, please follow the steps below as they may resolve any potential faults. If issues persist, please call us on **1300 759 637**.

- 1 First, turn off your nbn® NTD (connection box) and your wireless router.
- 2 Wait for about 10 minutes.
- Turn your nbn® NTD (connection box) back on.
- Wait another minute, then turn your wireless router back on.

Note: Please refer to the cabling setup provided on the 'How to Connect' page. This cabling setup is essential for an active connection.

#### Need some help?

If things don't go to plan and you require assistance, please contact our friendly Brisbane-based team.

Contact us on 1300 759 637 or via LiveChat at skymesh.net.au.

#### We're open:

8am - 8pm Monday to Friday

9am - 5pm Weekends

9am - 5pm Public Holidays

Australian Eastern Standard Time (AEST)

