

Tenda V12 - Fixed Wireless


WiFi Router Setup Guide

How to connect

Setting up your new router

Skymesh routers arrive pre-configured. Simply plug in the supplied cables as per the diagram, switch on the new router and connect to it using the supplied WiFi password.

Note: This cabling setup is essential for an active connection. Please avoid changing the cabling setup below to prevent disconnection.



Tenda V12 Please plug into the yellow port number 4

nbn® Fixed Wireless NTD

Please plug into the UNI-D sent via email

Warranty

Your new router comes with a 3-year advanced replacement warranty for full peace of mind. More information on our warranty can be found at **skymesh.net.au/warranty**

Understand your nbn® NTD lights

Learn more about your nbn® NTD (Connection Box). If you are offline, please check the cabling setup on the 'How to Connect' page and restart your internet connection. If issues persist, please call us on **1300 759 637**.

Light	State	Meaning
Power		No power supply. All other lights will be off if the nbn® NTD has no power.
		nbn® NTD is operating on backup battery power and power is low (if a battery has been fitted).
		nbn® NTD has power.
	*	nbn® NTD is operating on backup battery power (if a battery has been fitted).
Status		nbn® NTD has no power or is in an unexpected state.
		A system fault is detected.
	÷.	nbn® NTD is booting up/initialising.
		nbn® NTD is in test mode.
	÷.	nbn® NTD is operating normally.
Outdoor Unit (ODU)		nbn® NTD has no power or is in an unexpected state.
		nbn® NTD is offline.
		An error is detected.
		nbn® NTD is online.
		Network activity.
Signal Strength		nbn® NTD has no power or is offline.
	•	Low signal strength (this is not necessarily a service fault as factors such as local weather can impact signal strength).
		Medium signal strength.
		High signal strength.

How to restart your internet connection

If you're offline, please follow the steps below as they may resolve any potential faults. If issues persist, please call us on **1300 759 637**.

First, turn off your nbn® NTD (connection box) and your wireless router.

2 Wait for about 10 minutes.

1

Δ

3 Turn your nbn[®] NTD (connection box) back on.

Wait another minute, then turn your wireless router back on.

Note: Please refer to the cabling setup provided on the 'How to Connect' page. This cabling setup is essential for an active connection.

Need some help?

If things don't go to plan and you require assistance, please contact our friendly Brisbane-based team.

Contact us on **1300 759 637** or via LiveChat at **skymesh.net.au**.

We're open:

8am - 8pm Monday to Friday 9am - 5pm Weekends 9am - 5pm Public Holidays

Australian Eastern Standard Time (AEST)



skymesh.net.au